








Supplied with: 4 x screws 4 x Wall plugs 1 x Hex key 1 x Remote control

Step 1: Find a sunny location to install the bollard light.







Step 3

Remove the bollard and drill out the 4 x holes marked for 8mm screws.



Step 4

Insert the wall plugs into the drilled hole. Replace the bollard body lining up the 4 x holes at the base. Secure in place with 8mm screws.

Step 5



Remove silicon bun located above/below the NexSun plate. Insert the hex key in the hole and push the switch. Replace the silicone bung. When the light is not in use please switch off.



Use the remote control instructions below to set up the light.



Maintenance:

Clean the solar panel regularly or if it becomes soiled with a damp cloth to maintain optimal performance.

Quick start guide:

One remote can control up to 50 lights at the same time, up to 25 meters in open air.

- Point the remote at a light (within 25 metres), press the On button.

3 Modes:

Default: Automatically turns ON/OFF

dusk till dawn, cool/warm white

light for 16 hours.

Mode 2: Automatically turns ON/OFF

dusk till dawn, for 16 hours in your chosen colour.

4H _{TIME} 8н

Automatically turns ON/OFF dusk till dawn for 4 or 8 hours.

The light will flash twice to indicate this mode has been

selected.



NexSun is a brand of NightSearcher Ltd.

NightSearcher Limited Unit 4 Applied House, Fitzherbert Spur, Farlington, Portsmouth, Hampshire, PO6 1TT, UK T: +44 (0)23 9238 9774 E: sales@nightsearcher.co.uk

All NexSun products have a 3 year standard warranty on all manufacturing defects and 2 years on rechargeable batteries from the date of purchase. A replacement battery can also be purchased.

Please visit www.nexsun.co.uk for warranty information, proof of purchase is required.







Product weight	4.3kg
Product size	900mmx255Ø
NS Part No.	NEXSUN-BOLLARD-C

Product weight	4.8kg
Product size	900mmx255Ø
NS Part No.	NEXSUN-BOLLARD-S